




OEM RESPONSIBILITY




CUMMINS RESPONSIBILITY




SENSOR CONNECTOR




ACTUATOR CONNECTOR




SENSOR CONNECTOR




OEM CONNECTOR



ACTUATOR CONNECTOR



SENSOR CONNECTOR



NOTE: SOME OF THE CIRCUITS SHOWN HERE WILL NOT BE ACTIVE IN ALL APPLICATIONS. CONSULT THE EQUIPMENT MANUFACTURER'S LITERATURE TO DETERMINE WHICH CIRCUITS ARE USED.